

Smart Home Security Set - Basic



Wifi Network



Home Security



Frequency



FontaHome App



Push Notifications

Produkt Info



Provide complete security for your home with the Fontahome Smart Home Security Starter Set. It includes a motion detector, a siren and two door/window sensors. Via the FontaHome app the devices are integrated into a pre-existing Home Wifi network and can be managed through it. Through Scenes/Automations individual scenarios can be programmed. With this you can, for example set the siren to sound off when one of the Door/Window sensors is activated or the motion detector has detected movement. You can then receive push notifications to all smartphones and tablets that are connected to the App. Additionally the devices also support the services of IFTTT via the FontaHome app, which provides you with endless possibilities for the use of your smart home devices. All devices included in this set can be combined with all other FontaHome products.

Siren:

- WiFi Standard: Generation 4 (2,4 GHz), Range 45 m
- Volume warning tone: 90db
- Warning tones: 10 different sounds
- Power supply: Micro-USB, 5V-0.1A
- Back up power supply: 2 x Battery CR123A-3V
- Operating temperature: 0°C - 40°C
- Operating humidity: 20% - 85%.
- Dimensions: 68 mm x 68 mm x 33 mm

Motion Detector:

- WiFi Standard: Generation 4 (2,4 GHz), Range 45 m
- Detection angle: 110°
- Detection Range: 7 meters
- Power supply: 1 x Battery CR123A-3V
- Battery life: 5 years
- Standby power consumption: 13µA
- Operating temperature: 0°C - 40°C
- Operating humidity: 20% - 85%.
- Dimensions: 48 mm x 48 mm x 48 mm
- Weight: 46 g

Door/Window Sensor:

- WiFi Standard: Generation 4 (2,4 GHz), Range 45 m
- Power supply: 1 x Battery CR2-3V
- Battery life: 2 years
- Standby power consumption: 10µA
- Operating temperature: 0°C - 40°C
- Operating humidity: 20% - 85%.
- Dimensions: 72 x 32 x 25 mm / 40 x 11 x 11 mm

Art.No:254406

EAN:4024559254406